



P54.10-2442-08

1 Clutch

X58/1 Interior socket

	Remove/Install		
1	Open luggage compartment		
2	Pull interior socket (X58/1) out of paneling		
3	Separate coupling (1)		
4	Remove interior socket (X58/1)		
5	Install in the reverse order		
6	Read out fault memory and erase	Faults stored due to simulations, or cables being disconnected for assembly/testing operations, must be processed and erased from the fault memories after the work is completed.	
	Connect STAR DIAGNOSIS and read out fault memory	Diagnosis system STAR DIAGNOSIS	AD00.00-P-2000-04A *WH58.30-Z-1048-13A

Commercially available tools

Number	Designation
WH58.30-Z-1048-13A	STAR DIAGNOSIS diagnosis system, Compact Passenger Car 6511 1801 00